

Manual Supplement

Manual Title:	150X Series Calibration Supplement	Issue:	7
Part Number:	2465477	Issue Date:	11/14
Print Date:	November 2005	Page Count:	1
Revision/Date:	1, 7/07		

This supplement contains information necessary to ensure the accuracy of the above manual. Enter the corrections in the manual if either one of the following conditions exist:

1. The revision letter stamped on the indicated PCA is equal to or higher than that given with each change.
2. No revision letter is indicated at the beginning of the change.

Change #1

On page 18, Table 5, **Step 8**, under **Display Reading Limits** for **1507/1508**:

Change: 0.6 to 0.15

To: 0.05 to 0.15

Change #2



On page 25, Table 10, **Adjustment Step C-03**, under **Input Value** Column:

Change: 0.18 mA 0 Hz

To: 20 μ A, 0 Hz

Change #3

On page 2, add the following to the Symbols table:

	Conforms to relevant South Korean EMC Standards.
	Conforms to CAN/CSA-C22.2 No. 61010-1, second edition, including Amendment 1.

Change #4, 61173

On page 3, under **General Specifications**, replace **Altitude** with:

Altitude..... Operating: 2000 m CAT IV 600 V, Non Operating (Storage): 12,000 m

Change #5, 64919, 65176, 367

On page 3, under **General Specifications**, remove **Shock, Electromagnetic Compatibility, Safety, Certifications**, and add:

Safety..... IEC 61010-1: 600 V CAT IV, Pollution Degree 2

Electromagnetic Environment..... IEC 61326-1: Portable

Electromagnetic Compatibility..... Applies to use in Korea only. Class A Equipment (Industrial Broadcasting & Communication Equipment) ^[1]

[1] This product meets requirements for industrial (Class A) electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and is not to be used in homes.

Change #6, 79

On page 20, under **Testing the OHM Function**, replace steps 1 and 4:

1. Connect the UUT **COM** and **Ω** terminals to the Fluke 5320A low resistance output terminals in a 2-wire configuration.
4. Apply the calibrator output listed in Table 9, steps 1-3. Prior to step 1, set the 5320A Ohms output to Short and press the ZERO button on the UUT. Change the 5320A Ohms to 2-Wire mode.